Modicon LMC058 Motion Controller

Programming Guide

10/2010

EIO0000000408.02

www.schneider-electric.com

Schneider Electric

The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of Schneider Electric.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

© 2010 Schneider Electric. All rights reserved.

Modicon TM5 Expansion Modules Configuration Programming Guide	EIO0000000420 (ENG); EIO0000000421 (FRE); EIO0000000422 (GER); EIO0000000423 (SPA); EIO0000000424 (ITA); EIO0000000425 (CHS)
Modicon TM5 PCI Modules Configuration Programming Guide	EIO0000000590 (ENG); EIO0000000591 (FRE); EIO0000000592 (GER); EIO0000000593 (SPA); EIO0000000594 (ITA); EIO0000000595 (CHS)
Modicon LMC058 Motion Controller System Functions and Variables LMC058 PLCSystem Library Guide	EIO0000000566 (ENG); EIO0000000567 (FRE); EIO0000000568 (GER); EIO0000000569 (SPA); EIO0000000570 (ITA); EIO0000000571 (CHS)
Modicon LMC058 Motion Controller High Speed Counting LMC058 Expert I/O Library Guide	EIO0000000554 (ENG); EIO0000000555 (FRE); EIO0000000556 (GER); EIO0000000557 (SPA); EIO0000000558 (ITA); EIO0000000559 (CHS)
Modicon LMC058 Motion Controller Pulse Width Modulation LMC058 Expert I/O Library Guide	EIO0000000560 (ENG); EIO0000000561 (FRE); EIO0000000562 (GER); EIO0000000563 (SPA); EIO0000000564 (ITA); EIO0000000565 (CHS)
SoMachine Modbus and ASCII Read/Write Functions PLCCommunication Library Guide	EIO0000000361 (ENG); EIO0000000362 (FRE); EIO0000000363 (GER); EIO0000000364 (SPA); EIO0000000365 (ITA); EIO0000000366 (CHS)